

912K PGM 2-Way Garment Rolling Rack

Assembling Guide

 (1) BASE
 1 pc.

 (2) SPRING
 1 pc.

 (3) INNER POLE
 1 pc.

 (4) OUTER POLE
 1 pc.

 (5) ARM
 1 pc.

 (6) TOPPER
 1 pc.

(5)





(2)

(6)



1





<u>Step 2</u>

Gently place SPRING on top of the BASE.

<u>Step 1</u> Place BASE firmly on the ground.

Step 3 Insert INNER POLE into the BASE through SPRING.





Step 4 Slide OUTER POLE over INNER POLE.



The top of INNER POLE must be aligned like this when stepping down the foot pedal.

When you are sliding OUTER POLE over INNER POLE, make sure you are stepping down on the foot pedal with the top of INNER POLE aligned







Congratulations !!! Installation complete.